

DESKTOP AC

INSTRUCTION MANUAL

Functions










Includes







5 Power cord Ice Tray Water Curtain Manual

Specification

Working Voltage:	5V 1A
Max power:	4.5 W
LED:	Blue
Water Capacity:	200 ML
Water capacity of ice tray:	70 ML

Tips

- 1. The Desktop AC should be placed on a flat surface to avoid water leaking.
- 2. For best cooling results, pre-soak the water curtain and also have the ice tray frozen with water before use.
- 3. Freeze the extra ice tray so that you have a spare on hand when the first one melts.
- 4. When not in use please turn off the Desktop AC and then unplug the power cord.
- 5. Avoid inserting appendages into the fan all times while it is on to prevent damage to your and the device.
- 6. When cleaning and maintaining the device, make sure to switch off the device before unplugging the power cord, wait until the fan blades have stopped moving.


Care And Cleaning

- 1. We recommend a weekly cleaning of your water curtain to maintain its best performance.
- Hand-wash with mild soap and lukewarm water only. Do not use harsh chemicals or high temperature water or steam to clean. Remove excessive water and let it air dry.
- Replace with genuine water curtain every 3-6 months.

Steps to Install water tank/ice tray/

2. If the Desktop AC is not in use for a long time, please clean the water in the water tray and keep the water curtain as dry as possible.

Product Components



Instructions


Turning ON/OFF

First connect the device to a power source, turn the knob clock-wise there should be a click. Continue turning to increase fan speed. Turn the knob counter clock-wise () to reduce fan speed or to switch off the device.

(Note: Each time you turn on the power, make sure the knob is in the off position.)

LED control

Press the LED button to turn the light on and off.








fan speed adjust

Steps to take out the ice tray/ water curtain/water tank







Remove the ice tray by



Either use the pull tab or hold the whole water curtain.




To take out the water tank

You can only remove the water tank after you have removed the ice tray and water curtain.

How to prepare the ice tray and water curtain

before using the Desktop AC for quicker results.





7




Put the travs into the freezer to



Insert the water tank before

putting the ice tray and water

water curtain





Insert the ice tray

Install the top cover

Empty the water tank every time you change the ice tray to avoid water overflow when it melts.

To order a replacement water curtain:

support@buyblaux.com

The device complies with the European Directives 2014/30/EU.

At the end of its service life, this product may not be disposed of in the normal household waste, but rather must be disposed of at a collection point for recycling electrical and electronic devices. The materials are recyclable according to their labelling. You make an important contribution to protecting administration where the appropriate disposal facility is

Subject to change.

FRONT SIDE

BACK SIDE

IM Dimensions: 80x130mm折叠好尺寸

黑白双面印刷 157克铜版纸 风琴折